







Ordering spares / Ersatzteil - Regelung / Pièces de rechange / Parti di ricambio / Lista de recambios / Onderdelen bestellen (NL/B) / Κωδικοί Ανταλλακτικών / Bestilling af reservedele / Beställning av reservdelar / Bestilling av reservedeler / Резервни части / Запчасти / Części zapasowe / Pieśe de schimb / Rendelhető alkatrészek / Запасні частини / Резервни делови / Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezerves daļas / Náhradní díly / Náhradné diely / Yedek parça siparişi / Nadomestni deli

XX = AA, AD,

- | | |
|-------------------------|------------------|
| 1 - B 961827 XX | 9 - B 961906 NU |
| 2 - A 963751 NU | 10 - B 961907 NU |
| 3 - B 961815 XX | 11 - B 961908 NU |
| 4 - B 961814 NU | 12 - B 961909 XX |
| 5 - A 861397 NU | 13 - B 961910 NU |
| 6 - A 964520 NU | 14 - B 961582 NU |
| 7 - B 960364 NU - L620 | 15 - A 961335 NU |
| 7a - A 962005 NU - L500 | 16 - A 860666 NU |
| 8 - B 961905 XX | 17 - B 961941 NU |






GUSTO




Ideal Standard








11.2023 / B565318

B D425 ..





Ideal Standard International NV
Corporate Village - Gent Building
Da Vincilaan 2
1935 Zaventem
Belgium
<http://www.idealstandardinternational.com>





P	T	S	4	3	2	1	0
			°C	°C	°C	°C	°C
50°C	15°C	15°C	27	33	41	48	50
65°C	15°C	15°C	33	42	53	63	65
85°C	15°C	15°C	41	53	68	83	85



P	bar	MAX. 10	5	Q (3 bar)
T	°C	MAX. 80	65	l/min
			40	6,5