

Operating Guide


# VS 2 DN 15-25




MAINTENANCE  
FREE




VL046.1/02




VS 2




AMV(E) 10 +  
VS 2 DN 15-25





AMV(E) 13 +  
VS 2 DN 15-25




AMV(E) 20/30, 23/33 +  
VS 2 DN 15-25




AMV 150 +  
VS 2 DN 15




IP 54  
AMV 150






IP 54  
AMV(E) 13






IP 54  
AMV(E) 20/30, 23/33



IP 54  
AMV(E) 10



VS 2



DN	H <sub>1</sub>	H <sub>2</sub>	H <sub>3</sub>	H <sub>4</sub>
15	142	145	155	140
20	149	152	162	-
25	155	158	168	-

Type	AMV 150	AMV 10/13	AME 10/13	AMV(E) 20/23	AMV(E) 30/33
VS 2 DN 15	•	•	-	-	-
VS 2 DN 20	-	•	•	•	•
VS 2 DN 25	-	•	•	•	•