


Ordering spares / Ersatzteil - Regelung / Pièces de rechange / Parti di ricambio / Lista de recambios / Onderdelen bestellen (NL/B) / Κωδικοί Ανταλλακτικών / Bestilling af reservedele / Beställning av reservdelar / Bestilling av reservedeler / Резервни части / Запчасти / Części zapasowe / Piese de schimb / Rendelhető alkatrészek / Запасні частини / Резервни делови / Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezerves daļas / Náhradní díly / Náhradné diely / Yedek parça siparişi / Nadomestni deli

XX = AA, AD, .....





- 1 - A 861419 XX
- 2 - A 963751 NU
- 3 - A 861420 XX
- 4 - A 861397 NU
- 5 - B 961802 XX - BD408..
- B 961805 XX - BD546..
- B 961804 XX - BD410..
- 6 - B 960497 NU - BD408..
- B 961901 NU - BD546..
- B 961791 NU - BD410..
- B 960500 NU - BD410..

- 6a - A 960196 NU
- 7 - B 960839 NU
- 8 - B 960583 NU
- 9 - B 961806 XX
- 10 - B 961807 NU
- 11 - A 962370 NU
- 12 - B 960845 NU

BD410..



	P	bar		MAX. 10			Q (3 bar)
	T	°C		MAX. 80			l/min
						BD408..	9
						BD546..	4,5





GUSTO




Ideal Standard
















05.2023 / B565215



Ideal Standard International NV  
Corporate Village – Gent Building  
Da Vincilaan 2  
1935 Zaventem  
Belgium

<http://www.idealstandardinternational.com>





P	°C	°C	4	3	2	1	0
			°C	°C	°C	°C	°C
0,3 MPa 3 bar	50°C	15°C	27	33	41	48	50
	65°C	15°C	33	42	53	63	65
	85°C	15°C	41	53	68	83	85