







Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /  
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /  
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /  
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb  
 / Rendelhető alkatrészek / Застасні частини / Резервни делови / Резервни делови /  
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļi




XX = AA, GN, ...

Pos.	Part No.
1	A 861 781 XX
2	B 961 373 XX
3	B 960 650 NU
4	B 961 374 NU
5	A 861 156 NU
6	A 861 793 NU
7	A 861 376 NU
8	A 861 788 XX
9	A 861 498 NU
10	N 0429 77 NU
11	BE 175 XX
12	B 961 931 XX





13	A 861 789 NU
14	A 861 790 XX
15	A 861 791 XX
16	A 861 792 XX
17	A 5803 XX
18	BC 774 XX



  
**Ideal Standard**






**LA DOLCE VITA**  
**BD 674 ..**

1024 / A 869 103



Ideal Standard International NV  
 Corporate Village – Gent Building  
 Da Vincilaan 2  
 1935 Zaventem  
 Belgium  
<https://www.idealstandard.com>





	<b>P</b> bar		MAX. 10		5		<b>Q</b> (3 bar)
	<b>T</b> °C		MAX. 80		65		<b>I/min</b>
					55		8 12