





Ordering spares / Ersatzteil - Regelung / Pièces de rechange / Parti di ricambio / Lista de recambios / Onderdelen bestellen (NL/B) / Κωδικοί Ανταλλακτικών / Bestilling af reservedele / Beställning av reservdelar / Bestilling av reservedeler / Резервни части / Запчасти / Części zapasowe / Piese de schimb / Rendelhető alkatrészek / Зпасні частини / Резервни делови / Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezerves daļas / Náhradní díly / Náhradné diely / Yedek parça siparişi / Nadomestni deli

XX = AA, AD,

- 1 - B 961580 XX
- 2 - B 960473 XX
- 3 - B 961438 XX
- 4 - B 961374 NU
- 5 - A 861181 NU
- 6 - A 861156 NU
- 7 - B 961582 NU
- 8 - A 960911 NU
- 9 - B 961588 XX
- 9a - B 961581 NU
- 10 - B 960712 XX
- 11 - A 962574 NU
- 12 - B 960255 NU
- 13 - B 960535 NU
- 14 - A 960944 NU
- 15 - B 960460 NU
- 16 - A 961817 NU





	P	bar					Q (3 bar)	
	T	°C				l/min	9	
							B D643 ..	6



Ideal Standard

CERALOOK

01.2023 / B665863



B C176 XX
B D643 XX

B C178 XX



Ideal Standard International NV
Corporate Village – Gent Building
Da Vincilaan 2
1935 Zaventem
Belgium
<http://www.idealstandardinternational.com>

