





Ordering spares / Ersatzteil - Regelung / Pièces de rechange / Parti di ricambio / Lista de recambios / Onderdelen bestellen (NL/B) / Κωδικοί Ανταλλακτικών / Bestilling af reservedele / Beställning av reservdelar / Bestilling av reservedeler / Резервни части / Запчасти / Części zapasowe / Piese de schimb / Rendelhető alkatrészek / Запасні частини / Резервни делови / Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezerves daļas / Náhradní díly / Náhradné diely / Yedek parça siparişi / Nadomestni deli






XX = AA, AD,

- 1 - B 961813 XX
- 2 - A 963751 NU
- 3 - B 961815 XX
- 4 - B 961814 NU
- 5 - A 861397 NU
- 6 - B 961582 NU
- 7 - B 961816 XX

- 8 - B 961820 XX
- 9 - A 962575 NU
- 10 - B 961807 NU
- 11 - A 962005 NU
- 11a - A 963600 NU
- 12 - A 860984 NU
- 13 - B 960465 XX
- 14 - B961346NU
- 15 - A 962630 NU



P	°C	°C	4	3	2	1	0
			°C	°C	°C	°C	°C
0,3 MPa 3 bar	50°C	15°C	27	33	41	48	50
	65°C	15°C	33	42	53	63	65
	85°C	15°C	41	53	68	83	85




GUSTO



Ideal Standard


06.2023 / B565235















B D415 ..



Ideal Standard International NV
Corporate Village – Gent Building
Da Vincilaan 2
1935 Zaventem
Belgium

<http://www.idealstandardinternational.com>





	P	bar				Q (3 bar)
	T	°C				l/min
						6