





Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /  
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /  
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /  
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Pieśe de schimb /  
 Rendelhető alkatrészek / Запасні частини / Reservní delovi / Резервни делови /  
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daju

**Position**

1	A 962 040 AA
2	A 962 042 AA
3	A 961 667 NU
4	A 960 567 NU
5	A 963 154 NU
6	A 963 395 NU
7	A 963 309 NU
8	A 962 043 NU
9	A 960 001 NU
10	A 962 044 AA
11	A 962 045 NU
12	A 962 370 NU
13	A 963 404 NU
14	A 961 230 AA
15	A 960 019 AA
16	B 964 902 AA






**Ideal Standard**

**MELANGE**

1220 / A868736





**A 4258 .. A 4260 .. A4268 .. A4287 ..  
 A 5962 ..**



Ideal Standard International NV  
 Corporate Village - Gent Building  
 Da Vincilaan 2  
 1935 Zaventem  
 Belgium

www.idealstandardinternational.com





	<b>P</b>	<b>bar</b>	0,5		MAX. 10	1		<b>Q</b> (3 bar)
	<b>T</b>	<b>°C</b>			MAX. 80			<b>l/min</b>
						65 40		<b>13</b>