

540



Subway 2.0

7113 6G / 6J / 6H / KG

AUSSCHNITTSCHABLONE
GABARIT POUR DECOUPE
TEMPLATE FOR CUTTING


445

Nach Einkleben mit Silikon, 24 Stunden ruhen lassen.
Erst 24 Stunden nach dem Einkleben transportieren.

After attaching with silicone, leave for 24 hours.
Leave to dry for 24 hours before transporting.

Après collage au silicone, laisser reposer 24 heures.
Laisser sécher 24 heures avant le transport.

SILIKON KAUSCHUK
SILICONE RUBBER
MASTIC PLASTIFANT



70

